



**YAMAHA**

**RD350/350F '85**

**57V-AE1**

**SUPPLEMENTARY  
SERVICE MANUAL**



## **FOREWORD**

This Supplementary Service Manual has been prepared to introduce new service and new data for the RD350/350F. For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with following manual:

**RD250LC/350LC Service Manual 31L-28197-80**

**RD350/350F  
SUPPLEMENTARY SERVICE MANUAL  
©1984 by Yamaha Motor Co., Ltd.  
1st Edition, October 1984  
All rights reserved. Any reprinting or  
unauthorized use without the written  
permission of Yamaha Motor Co., Ltd.  
is expressly prohibited.**

## NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical concepts and procedures inherent in motorcycle repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit to use and/or unsafe.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

TECHNICAL PUBLICATIONS  
SERVICE DIVISION  
MOTORCYCLE OPERATIONS  
YAMAHA MOTOR CO., LTD.

## HOW TO USE THIS MANUAL

### PARTICULARLY IMPORTANT INFORMATION

This material is distinguished by the following notation.

**NOTE:** A NOTE provides key information to make procedures easier or clearer.

**CAUTION:** A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle.

**WARNING:** A WARNING indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

### MANUAL FORMAT


All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings
- Pitting/Damage→Replace.

### EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.



## ILLUSTRATED SYMBOLS (Refer to the illustration)

Illustrated symbols ① to ⑧ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Periodic inspection and adjustment
- ③ Engine
- ④ Cooling system
- ⑤ Carburetion
- ⑥ Chassis
- ⑦ Electrical
- ⑧ Appendices

Illustrated symbols ⑨ to ⑯ are used to identify the specifications appearing in the text.

- ⑨ Filling fluid
- ⑩ Lubricant
- ⑪ Tightening
- ⑫ Wear limit, clearance
- ⑬ Engine speed
- ⑯ Ω, V, A

Illustrated symbols ⑮ to ㉑ in the exploded diagram indicate grade of lubricant and location of lubrication point.



- ⑮ Apply engine oil
- ⑯ Apply gear oil
- ⑰ Apply molybdenum disulfide oil
- ⑱ Apply wheel bearing grease
- ⑲ Apply lightweight lithium-soap base grease
- ㉑ Apply molybdenum disulfide grease
- ㉑ Apply locking agent (LOCTITE®)



## CONTENTS

<b>GENERAL INFORMATION .....</b>	D-5
<b>MOTORCYCLE IDENTIFICATION .....</b>	D-5
Frame serial number .....	D-5
Engine serial number .....	D-5
<b>PERIODIC INSPECTIONS AND ADJUSTMENTS .....</b>	D-5
<b>INTRODUCTION .....</b>	D-5
<b>MAINTENANCE INTERVALS CHARTS .....</b>	D-5
Periodic maintenance/lubrication .....	D-5
<b>COWLING REMOVAL .....</b>	D-6
<b>ENGINE .....</b>	D-7
Oil pump .....	D-7
<b>CHASSIS .....</b>	D-9
Front fork oil change .....	D-9
Front fork adjustment .....	D-9
Front fork and rear shock absorber settings .....	D-10
<b>CHASSIS .....</b>	D-11
<b>FRONT AND REAR BRAKE .....</b>	D-11
Caliper pad replacement .....	D-11
Caliper disassembly .....	D-12
Brake master cylinder .....	D-13
<b>FRONT FORK .....</b>	D-15
Removal .....	D-16
Disassembly .....	D-16
Inspection .....	E-1
Reassembly .....	E-1
Installation .....	E-2
<b>APPENDICES .....</b>	E-3
<b>SPECIFICATIONS .....</b>	E-3
General specifications .....	E-3
Maintenance specifications .....	E-4
<b>GENERAL TORQUE SPECIFICATIONS .....</b>	E-8
<b>DEFINITION OF UNITS .....</b>	E-8
<b>CABLE ROUTING .....</b>	E-9





## GENERAL INFORMATION

### MOTORCYCLE IDENTIFICATION

#### FRAME SERIAL NUMBER

The frame serial number ① is stamped into the right side of the steering head pipe.

#### ENGINE SERIAL NUMBER

The engine serial number ① is stamped into the elevated part of the left rear section of the engine.

#### NOTE: \_\_\_\_\_


The first three digits of these numbers are for model identifications; the remaining digits are the unit production number.

#### Starting Serial Number:

RD350	1JF	31K-077101
	1JG	31K-085101
RD350F	57V	31K-053101
	1AF	31K-072101

#### NOTE: \_\_\_\_\_

Designs and specifications are subject to change without notice.





## PERIODIC INSPECTIONS AND ADJUSTMENTS

## INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

MAINTENANCE INTERVALS CHARTS  
PERIODIC MAINTENANCE/LUBRICATION

Unit: km (mi)

ITEM	REMARKS	BREAK-IN 1,000 (600)	EVERY	
			6,000 (4,000) or 6 Months	12,000 (8,000) or 12 Months
Spark plug(s)	Check condition. Clean or replace if necessary.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Air filter	Clean. Replace if necessary.		<input type="radio"/>	<input type="radio"/>
Carburetor*	Check idle speed (/synchronization)/ starter operation. Adjust if necessary.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Fuel line*	Check fuel hose (and vacuum pipe) for cracks or damage. Replace if necessary.		<input type="radio"/>	<input type="radio"/>
Transmission oil*	Check oil level/oil leakage. Correct if necessary. Replace every 24,000 (16,000) or 24 months. (Warm engine before draining.)	REPLACE	<input type="radio"/>	<input type="radio"/>
Autolube pump*	Check operation. Correct if necessary. Air bleeding.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Brake*	Check operation/fluid leakage/See NOTE. Correct if necessary.		<input type="radio"/>	<input type="radio"/>
Clutch	Check operation. Adjust if necessary.		<input type="radio"/>	<input type="radio"/>
Rear arm pivot*	Check rear arm assembly for looseness. Correct if necessary. Moderately repack every 24,000 (16,000) or 24 months.			<input type="radio"/>
Rear suspension link pivots*	Check operation. Apply grease lightly every 24,000 (16,000) or 24 months.			<input type="radio"/>
Wheels*	Check balance/damage/runout. Repair if necessary.		<input type="radio"/>	<input type="radio"/>
Wheel bearings*	Check bearings assembly for looseness/damage. Replace if damaged.		<input type="radio"/>	<input type="radio"/>
Steering bearing*	Check bearings assembly for looseness. Correct if necessary. Moderately repack every 24,000 (16,000) or 24 months. **	<input type="radio"/>		<input type="radio"/>
Front forks*	Check operation/oil leakage. Repair if necessary.		<input type="radio"/>	<input type="radio"/>
Rear shock absorber*	Check operation./oil leakage. Repair if necessary.		<input type="radio"/>	<input type="radio"/>

**INSP****ADJ****MAINTENANCE INTERVALS CHARTS**

Unit: km (mi)

ITEM	REMARKS	BREAK-IN 1,000 (600)	EVERY	
			6,000 (4,000) or 6 Months	12,000 (8,000) or 12 Months
Cooling system	Check coolant leakage. Repair if necessary. Replace coolant every 24,000 (16,000) or 24 months.		<input type="radio"/>	<input type="radio"/>
Drive chain	Check chain slack/alignment. Adjust if necessary. Clean and lube.	EVERY 500 (300)		
Fittings/Fasteners*	Check all chassis fittings and fasteners. Correct if necessary.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Center and sidestand*	Check operation. Repair if necessary.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Battery*	Check specific gravity. Check breather pipe for proper operation. Correct if necessary.		<input type="radio"/>	<input type="radio"/>

\*: It is recommended that these items be serviced by a Yamaha dealer.

\*\*: Medium weight wheel bearing grease.

\*\*\*: Lithium soap base grease.


**NOTE:**

Brake fluid replacement:


1. When disassembling the master cylinder or caliper cylinder, replace the brake fluid.  
Normally check the brake fluid level and add the fluid as required.
2. On the inner parts of the master cylinder and caliper cylinder, replace the oil seals every two years.
3. Replace the brake hoses every four years, or if cracked or damaged.

**COWLING REMOVAL****UPPER COWLING**


1. Remove:
  - Rear view mirrors
  - Mounting bolts
  - Speedometer




2. Remove:
  - Mounting bolts




3. Remove:
  - Flasher lights
  - Mounting bolts




4. Remove:
  - Mounting bolts
  - Upper cowling


**CENTER COWLING**

1. Remove:
  - Mounting bolts
  - Center cowling




**LOWER COWLING**


1. Remove:
  - Mounting bolts
  - Lower cowling

**ENGINE****OIL PUMP****Oil Pump Cable Adjustment**

1. Remove:
  - Lower cowling
  - Pump cover
2. Check:
  - Oil pump control position
  - Not aligned → Adjust.

**Oil pump cable adjustment steps:**

- Rotate the throttle grip slightly until all slack is removed from all cables. Hold this position.
- Check to see that Autolube pump plunger pin ① is aligned with the mark ② on the Autolube pump pulley.
- If the mark and pin are not in alignment, loosen cable length adjuster locknut ③ and adjust cable length until alignment is achieved.



② Adjuster

**Minimum Pump Stroke Adjustment**


1. While running the engine at idle, observe the pump adjust plate carefully. Stop the engine moment that the adjust plate moves out to its limit.

**2. Measure:**

- Gap (Between the raised boss on the pump adjust pulley and adjust plate)

**Minimum Pump Stroke:**

0.10 ~ 0.15 mm (0.004 ~ 0.006 in)

**NOTE:**

When inserting the thickness gauge between the adjust plate and the adjust pulley, be careful so that neither the plate nor the pulley is moved. In other words, do not force the thickness gauge into the gap.

**① Thickness gauge**

3. Repeat steps "2" and "3" above a few times. When the gap measured is the largest, the pump stroke is considered to be at a minimum.
4. If clearance is not correct, adjust as follows:

**a. Remove:**

- Locknut ①
- Spring Washer ②
- Adjust plate ③

**b. Remove or add:**


- Adjust shim ④

**c. Install:**

- Components in above list (step "a")

**d. Measure:**


- Gap




**Autolube Pump Air Bleeding**

The Autolube pump and delivery line must be bled on the following occasions:

- Setting up a new motorcycle out of the crate.
- Whenever the Autolube tank has run dry.
- Whenever any portion of the Autolube system is disconnected.

**[Bleeding the pump case and/or oil pipe]**

1. Remove:
  - Pump cover
  - Bleed screw ①
2. Keep the oil running out until air bubbles disappear.
3. Inspect:
  - Bleed screw gasket ②
  - Damage→Replace.
4. Install:
  - Components in above list

**[Bleeding the pump distributor and/or delivery pipe]**

1. Start the engine.
2. Pull the pump cable all the way out to set the pump stroke to a maximum.



**NOTE:**

It is difficult to bleed the distributor completely with the pump stroke at a minimum, and therefore the pump stroke should be set to a maximum.

3. Keep the engine running at about 2,000 r/min for two minutes or so, and both distributor and delivery pipe can be completely bled.




## CHASSIS

## FRONT FORK OIL CHANGE

## WARNING:

1. Fork oil leakage can cause loss of stability and safe handling. Have any problem corrected before operating the motorcycle.
2. Securely support the motorcycle so there is no danger of it falling over.



1. Place a suitable stand under the engine to raise the front wheel off the ground.


2. Remove:

- Air valve cap ①

## NOTE:

Keep the valve open by pressing it for several seconds so that the air can be let out of the inner tube.

② Push



3. Loosen:


- Pinch bolts (Handle crown ① and handlebar ②)

4. Remove:

- Cap bolt ③
- Spacer ④


5. Remove:

- Drain bolt ①
- Drain the fork oil.



## WARNING:

Do not allow any oil to contact the disc brake components. If oil is discovered, be sure to remove it, otherwise diminished braking capacity and damage to the rubber components of the brake assembly will occur.



## 6. Inspect:

- O-ring ① (Cap bolt)
- Wear/Damage → Replace.

## 7. Install:

- Drain bolt

## 8. Fill:

- Front fork



## Each Fork:

297 cm<sup>3</sup> (10.48 Imp oz, 10.04 US oz)

Fork Oil 10 wt or equivalent

After filling pump the forks slowly up and down to distribute the oil.

## 9. Install:

- Cap bolt
- Pinch bolts (Handle crown and handlebar)



## Cap Bolt:

23 Nm (2.3 m·kg, 17 ft·lb)

Pinch Bolt (Steering Crown):

20 Nm (2.0 m·kg, 14 ft·lb)

## 10. Adjust:

- Front fork air pressure

Refer to "Front fork and rear shock absorber setting" section.

## FRONT FORK ADJUSTMENT

**WARNING:**


Always adjust each air pressure to the same setting. Uneven adjustment can cause poor handling and loss of stability.

1. Elevate the front wheel by placing the motorcycle on the centerstand.

**INSP**  
**ADJ**



## FRONT FORK ADJUSTMENT



### NOTE:

When checking and adjusting the air pressure, there should be no weight on the front end of the motorcycle.

### 2. Adjust:

- Air pressure

#### Air pressure adjustment steps:

1. Remove the valve caps.
2. Using the air check gauge ①, check and adjust the air pressure.

#### Stiffer → Increase the air pressure

(Use an air pump or pressurized air supply)

#### Softer → Decrease the air pressure

(Release the air by pushing the valve)

#### Standard Air Pressure:

39.2 kPa (0.4 kg/cm<sup>2</sup>, 5.7 psi)

#### Maximum air Pressure:

78.5 kPa (0.8 kg/cm<sup>2</sup>, 11 psi)

#### Minimum Air Pressure:

Zero

#### CAUTION:

Never exceed the maximum pressure, or oil seal damage may occur.

#### WARNING:

The difference between both the left and right tubes should be 9.81 kPa (0.1 kg/cm, 1.4 psi) or less.

3. Install the valve caps securely.



## FRONT FORK AND REAR SHOCK ABSORBER SETTINGS

Use this table as a guide for specific riding and motorcycle load conditions.

	Front fork	Rear shock absorber	Loading condition			
			Solo rider	With accessory equipment	With passenger	With accessory equipment and passenger
1.	39.2 kPa (0.4 kg/cm <sup>2</sup> , 5.7 psi)	2	○			
2.	58.8 kPa (0.6 kg/cm <sup>2</sup> , 8.5 psi)	3		○		
3.	78.5 kPa (0.8 kg/cm <sup>2</sup> , 11.4 psi)	4			○	
4.	98.1 kPa (1.0 kg/cm <sup>2</sup> , 14.2 psi)	5				○



## CHASSIS

## FRONT AND REAR BRAKE

## CALIPER PAD REPLACEMENT

- ① Rubber cap
- ② Bleed screw
- ③ Retaining bolt
- ④ Pad spring
- ⑤ Pad
- ⑥ Shim
- ⑦ Dust seal
- ⑧ Piston seal
- ⑨ Piston


NOTE: \_\_\_\_\_

## FRONT BRAKE:

Install the pad spring with its longer tangs \* facing towards the disk rotation direction.

## FRONT AND REAR BRAKE:

Be sure to position the shim so that its arrow mark points in the direction of the disk plate rotation.





## Brake Inspection and Repair



## Recommended Brake Component Replacement Schedule:

Brake pads	As required
Piston seal, dust seal	Every two years
Brake hoses	Every four years
Brake fluid	Replace only when brakes are disassembled

## CALIPER PAD REPLACEMENT (FRONT AND REAR)

## NOTE: \_\_\_\_\_

It is not necessary to disassemble the brake caliper and brake hose to replace the brake pads.



## 1. Remove:

- Caliper bolts ①
- Retaining bolts ②

## 2. Remove:





- Pads

## NOTE: \_\_\_\_\_

Replace the pads as a set if either is found to be worn to the wear limit.



Pad Wear Limit:  
0.5 mm (0.02 in)



## 3. Install:

- Pads (New) ①
- Pad spring ②
- Retaining bolts ③
- Caliper ④
- Shim ⑤



## Caliper:

35 Nm (3.5 m·kg, 25 ft·lb)

## Retaining Bolt:

10 Nm (1.0 m·kg, 7.2 ft·lb)

## NOTE: \_\_\_\_\_

Install the pad spring indirection shown in the photo.

## NOTE: \_\_\_\_\_

## FRONT BRAKE ONLY

Insert the pads with their shims ① in direction of the arrow ②.


## CALIPER DISASSEMBLY (FRONT AND REAR)

## Disassembly

## 1. Remove:

- Brake hose ①  
Place the open hose end into a container and pump the old fluid out carefully.
- Retaining bolts ②
- Caliper ③
- Pads ④



## 2. Repeat previous step to remove the other calipers.



#### Caliper piston removal steps:


- Using a rag, lock the right side piston.
- Blow compressed air into the hose joint opening to force out the left side piston from the caliper body.
- Remove the dust and piston seals and reinstall the piston.
- Repeat previous step to force out the right side piston from the caliper body.

**A DO NOT LOSEN**



#### 3. Remove:

- Piston seal (1)
- Dust seal (2)



#### Inspection


##### 1. Inspect:


- Caliper piston  
Rust/Wear → Replace.
- Caliper cylinder body  
Wear/Scratches → Replace.

- Brake pads  
Out of specification → Replace.



**Pad Wear Limit:**  
0.5 mm (0.0197 in)



**Installation****1. Assemble:**

- Brake caliper(s)
- Reverse disassembly steps


**WARNING:**

- All internal parts should be cleaned in new brake fluid only.
- Internal parts should be lubricated with brake fluid when installed.



**Brake Fluid:**  
DOT #3

- Replace the dust and piston seals whenever a caliper is disassembled.

**2. Install:**

- Brake calipers
- Hoses

**3. Tighten:**

- Caliper bolts
- Hose union bolts (With copper washers)

**FRONT AND REAR****Brake Caliper:**

35 Nm (3.5 m·kg, 25 ft·lb)

**Retaining Bolt:**

10 Nm (1.0 m·kg, 7.2 ft·lb)

**Brake Hose:**


26 Nm (2.6 m·kg, 19 ft·lb)


- 4. Bleed the air completely from the brake system.



## BRAKE MASTER CYLINDER (FRONT)

- ① Master cylinder cap
- ② Rubber seal
- ③ Master cylinder kit
- ④ Copper washer
- ⑤ Brake hose holder
- ⑥ Brake hose




**Disassembly****NOTE:**

Drain the brake fluid before removing master cylinder.

- ① Dust boot
- ② Circlip
- ③ Piston
- ④ Piston cups
- ⑤ Return spring
- ⑥ Washer
- ⑦ Seat

**A** **MASTER CYLINDER KIT** (Replace as a set)

**1. Remove:**


- Brake light switch leads ①
- Brake lever ②
- Lever spring ③


**2. Disconnect:**

- Brake hose ④
- Drain the fluid

**3. Remove:**

- Master cylinder
- Master cylinder cap
- Drain the excess fluid
- Dust boot ①
- Circlip ②
- Master cylinder kit ③



**Inspection**

## 1. Inspect:


- Master cylinder body  
Scratches/Wear→Replace.

**NOTE:** \_\_\_\_\_

Clean all passages with new brake fluid.

- Brake hoses  
Cracks/Wear/Damage→Replace.
- Master cylinder kit  
Scratches/Wear→Replace.

① Oil baffle plate

**Installation**

## 1. Install:

- Master cylinder kit ①

**WARNING:** \_\_\_\_\_

Internal ports should be lubricated with brake fluid when installed.

- Circlip ②
- Dust boot ③


## 2. Install:

- Master cylinder
- Brake hose (With copper washers)
- Brake lever

**NOTE:** \_\_\_\_\_

Grease the pivot point.

- Brake switch leads.



## 3. Tighten:

- Master cylinder bolts
- Brake hose



## Master Cylinder:

10 Nm (1.0 m·kg, 7.2 ft·lb)

## Brake Hose:

26 Nm (2.6 m·kg, 19 ft·lb)

## 4. Bleed the air completely from the brake system

## 5. Tighten:

- Master cylinder cap



2 Nm (0.2 m·kg, 1.4 ft·lb)



## FRONT FORK

- ① Air valve
- ② Cap bolt
- ③ O-ring
- ④ Dust seal
- ⑤ Spacer
- ⑥ Spring seat
- ⑦ Fork spring
- ⑧ Piston ring
- ⑨ Damper rod
- ⑩ Rebound spring


- ⑪ Oil lock piece
- ⑫ Inner fork tube
- ⑬ Slide metal
- ⑭ Retaining clip
- ⑮ Oil seal
- ⑯ Plain washer
- ⑰ Slide metal
- ⑱ Outer fork tube
- ⑲ Drain screw
- ⑳ Cylinder securing bolt

T-HANDLE:

P/N. 90890-01326

DAMPER ROD HOLDER:

P/N. 90890-01294





## REMOVAL

## WARNING:

Securely support the motorcycle so it won't fall over when the front wheel and front forks are removed.

## 1. Remove:

- Brake caliper
- Front wheel
- Front fender
- Front fork brace




## 2. Remove:

- Air valve cap ①

## NOTE:

Keep the valve open by pressing it for several seconds so that the air can be let out of the inner tube.

② Push



## 3. Loosen:

- Pinch bolts (Handle crown and handlebar) ①
- Cap bolt ②
- Pinch bolts (Under bracket) ③

## 4. Remove:

- Front fork


## DISASSEMBLY

## 1. Remove:

- Cap bolt ①
- Spacer ②
- Spring seat ③
- Fork spring ④




## 2. Drain:

- Fork oil



## 4. Remove:

- Dust seal ①
- Retaining clip ②



## 5. Remove:

- Cylinder securing bolt

Use the Damper Rod Holder (90890-01294) ① and T-Handle (90890-01326) ② to lock the damper rod ③.

## 6. Remove:

- Damper rod ①
- Rebound spring ②

## 7. Remove:


- Inner fork tube

**Inner fork tube removal steps:**

- Hold the fork leg horizontally.
- Pull out the inner fork tube from the outer tube by forcefully, but carefully, withdrawing the inner fork tube.

**NOTE:** \_\_\_\_\_


- Excessive force will damage the oil seal, plain washer and/or bushings. The oil seal and bushings must be replaced.
- Avoid bottoming the inner tube in the outer tube during the above procedure, as the oil lock piece will be damaged.

**IN SPECTI****1. Inspect:**

- Inner fork tube  
Scratches/Bends→Replace.

**WARNING:**

**Do not attempt to straighten a bent inner fork tube as this may dangerously weaken the tube.**

**2. Inspect:**

- Outer fork tube  
Scratches/Bends/Damage→Replace.
- Fork spring  
Out of specification→Replace.




**Fork Spring Free Length:**

429.6 mm (16.9 in)

**Minimum Free Length:**


424 mm (16.7 in)

**3. Inspect:**

- Damper rod ①  
Wear/Damage→Replace.
- Ring ②  
Wear/Damage→Replace.

**NOTE:**

Blow out all oil passages with compressed air.

**4. Inspect:**


- Slide metals  
Wear/Damage→Replace



## REASSEMBLY

## NOTE:

Make sure all components are clean before assembly. Always install the new oil seal and the dust seal.




## 1. Install:

- Rebound spring ①
- Damper rod ②
- Slide the damper rod into the inner fork tube from its top.
- Oil lock piece ③
- Fit the oil lock piece over the damper rod sticking out of the inner fork tube.

## 2. Install:

- Cylinder securing bolt
- Use the Damper Rod Holder (90890-01294) and T-Handle (90890-01326) to lock the damper rod.


 20 Nm (2.0 m·kg, 14 ft·lb)  
LOCTITE®



## 3. Install:

- Slide metal ④
- Use the Fork Seal Driver Weight (90890-01367) ② and Adapter (90890-01370) ③.

① Inner tube  
⑤ Outer tube



## 4. Install:

- Plain washer ④
- Oil seal ③ (New)
- Use the Fork Seal Driver Weight (90890-01367) ① and Adapter (90890-01370) ②.
- Retaining clip
- Dust seal



## 5. Fill:

- Front fork



## Each Fork:


297 cm<sup>3</sup> (10.48 Imp oz, 10.04 US oz)

Fork Oil 10 wt or equivalent

'After filling, slowly pump the fork up and down to distribute oil.

## 6. Install:

- Fork spring  
(with smaller pitch side up)
- Spring seat
- Spacer
- Cap bolt (Temporarily)



## INSTALLATION

## 1. Install:

- Front fork(s)

Temporarily tighten the pinch bolts.

NOTE: \_\_\_\_\_

Level the top of the cap bolt with the top of the handlebar.

① Flush

## 2. Tighten:

- Pinch bolts (Underbracket)




## Pinch Bolt (Underbracket):

20 Nm (2.0 m·kg, 14 ft·lb)

NOTE: \_\_\_\_\_

Do not tighten the steering crown pinch bolt.



**3. Tighten:**

- Cap bolt ①
- Pinch bolts (Handle crown ② and handlebar ③)



**Cap Bolt:**

23 Nm (2.3 m·kg, 17 ft·lb)

**Pinch Bolt (Handle Crown):**

20 Nm (2.0 m·kg, 14 ft·lb)  
(Handlebar)

20 Nm (2.0 m·kg, 14 ft·lb)

**4. Adjust:**

- Front fork air pressure

Refer to "Front fork and rear shock absorber setting" section.

**5. Install:**

- Air valve cap
- Front fork brace
- Front fender
- Front wheel
- Brake caliper



**Front Fork Brace:**

10 Nm (1.0 m·kg, 7.2 ft·lb)

**Front Fender:**

10 Nm (1.0 m·kg, 7.2 ft·lb)

**Front Wheel Axel:**

75 Nm (7.5 m·kg, 54 ft·lb)

**Brake Caliper:**

35 Nm (3.5 m·kg, 25 ft·lb)



## APPENDICES

(DK): For Denmark

(S): For Sweden

(FL): For Finland

(G): For Germany

## SPECIFICATIONS

## GENERAL SPECIFICATIONS

Model	RD350/350F			
Model Code Number	57V	1JF	1AF(G)	1JG(G)
Frame Starting Number	31K-053101	31K-077101	31K-072101	31K-085101
Engine Starting Number	31K-053101	31K-077101	31K-072101	31K-085101
Dimensions:				
Overall Length	2,095 mm (82.5 in)	2,120 mm (83.5 in)	[G, DK, S]	
Overall Width	2,160 mm (85.0 in)	[FL]		
Overall Height	690 mm (27.2 in)	[350]	670 mm (26.4 in)	[350F]
Seat Height	1,190 mm (46.9 in)			
Wheelbase	800 mm (31.5 in)			
Minimum Ground Clearance	1,385 mm (54.5 in)			
165 mm ( 6.5 in)				
Weight:				
With Oil and Full Fuel Tank	161 kg (355 lb) [350]	165 kg (364 lb)	[350F]	
Minimum Turning Radius	2,700 mm (106 in)			
Engine:				
Type	Liquid cooled 2-stroke, gasoline, torque induction			
Cylinder Arrangement	Twin, forward inclined			
Displacement	347 cm <sup>3</sup>			
Bore × Stroke	64.0 × 54.0 mm (2.520 × 2.126 in)			
Compression Ratio	6.0 : 1			
Starting System	Primary kick starter			
Lubrication System	Separate lubrication (Yamaha Autolube)			
Engine Oil:				
Type	Yamaha oil 2T or equivalent,			
Tank Capacity	Air cooled 2-stroke engine oil			
	1.6 L (1.41 Imp qt, 1.69 Us qt)			
Transmission Oil:				
Type	SAE 10W30 type SE motor oil			
Oil Capacity Total	1.7 L (1.50 Imp qt, 1.80 US qt)			
Exchange	1.5 L (1.32 Imp qt, 1.59 US qt)			
Radiator Capacity (Including All Routes)	1.5 L (1.32 Imp qt, 1.59 US qt)			
Spark Plug:				
Type	BR8ES			
Gap	0.7 ~ 0.8 mm (0.02 ~ 0.03 in)			
Carburetor × Quantity/ Manufacturer	VM26SS × 2 / MIKUNI			
Air Cleaner	Wet foam rubber			



Model		RD350/350F
Clutch Type		Wet, multiple-disc
Transmission:		
Primary Reduction System		Helical gear
Primary Reduction Ratio		66/23 (2.870)
Secondary Reduction System		Chain
Secondary Reduction Ratio		39/17 (2.294) 40/17 (2.352) (G)
Transmission Type		Constant mesh 6-speed
Operation System		Left foot operation
Gear Ratio	1st	36/14 (2.571)
	2nd	32/18 (1.778)
	3rd	29/22 (1.318)
	4th	26/24 (1.083)
	5th	25/26 (0.962)
	6th	24/27 (0.889)
Chassis:		
Frame Type		Double cradle
Caster		26°
Trail		96 mm (3.78 in)
Fuel:		
Tank Capacity, Total		20.0 L (4.4 Imp gal, 5.28 US gal)
Reserve		2.0 L (0.44 Imp gal 0.53 US gal)
Tire		
Front		90/90-18 51H
Rear		110/80-18 58H
Braking System:		
Front		Double disc brake/Right hand operation
Rear		Single disk brake/ Right foot operation
Suspension:		
Front		Telescopic fork
Rear		Swing arm (New monocross suspension)
Shock Absorber:		
Front		Air, coil spring/oil damper
Rear		Gas, coil spring/oil damper
Wheel Travel:		
Front		140 mm (5.51 in)
Rear		100 mm (3.94 in)
Electrical:		
Ignition System		CDI
Generator System		A.C. generator
Battery:		
Type/ Capacity		12N5.5-3B/12V, 5.5AH



Model	RD350/350F
Bulb Wattage × Quantity:	
Headlight	60W/55W (Quartz bulb)
Tail/ Brake Light	12V, 5W/21W×2
Turn Light	12V, 21W×4
Meter Light	12V, 3.4W×5
Auxiliary Light	12V, 4W 3.4W (England)
Indicator Light:	
"NEUTRAL"	12V, 3.4W
"HIGH BEAM"	12V, 3.4W
"OIL"	12V, 3.4W
"TURN"	12V, 3.4W



## MAINTENANCE SPECIFICATIONS


## Engine

Model	RD350/350F
Cylinder Head:	
Combustion Chamber Volume	21.3 ~ 21.9 cm <sup>3</sup>
Distortion Limit	0.03 mm (0.0012 in)
Cylinder:	
Material	Aluminum alloy with cast iron sleeve (Cast in)
Bore Size /<Limit>	64 <sup>+0.02</sup> mm (2.52 <sup>+0.008</sup> in) / 64.1 mm (2.524 in)
Taper Limit	0.05 mm (0.0020 in)
Out of Round Limit	0.01 mm (0.0004 in)
Piston:	
Piston Size/ Measuring Point*	64.0 mm (2.520 in) / 10 mm (0.39 in)
Piston Clearance <Limit>	0.060 ~ 0.065 mm (0.0024 ~ 0.0026 in) 0.1 mm (0.004 in)
Piston Oversize	64.25, 64.50 mm (2.53, 2.54 in)
Piston Offset	0 mm (0 in)
Piston Ring:	
Piston Ring Design/ B × T (Top) (2nd)	Keystone/ 1.2 × 2.6 mm (0.047 × 0.102 in) Plain (With expander)/ 1.5 × 2.15 mm (0.059 × 0.085 in)
Ring End Gap (Installed) (Top) (2nd)	0.30 ~ 0.45 mm (0.012 ~ 0.018 in) 0.35 ~ 0.50 mm (0.014 ~ 0.020 in)
Ring Groove Side Clearance (Top) (2nd)	0.02 ~ 0.06 mm (0.0008 ~ 0.0024 in) 0.03 ~ 0.07 mm (0.0012 ~ 0.0028 in)
Crankshaft:	
Crankshaft Assembly Width (F)	54.00 <sup>+0</sup> <sub>-0.05</sub> mm (2.13 <sup>+0</sup> <sub>-0.002</sub> in)
(A)	156 <sup>+0.05</sup> <sub>-0.10</sub> mm (6.14 <sup>+0.002</sup> <sub>-0.004</sub> in)
Crankshaft Deflection Limit (S)	0.05 mm (0.002 in)
Connecting Rod Big End Side Clearance (D)	0.25 ~ 0.75 mm (0.01 ~ 0.03 in)
Connecting Rod Small End Deflection (P) <Limit>	0.36 ~ 0.98 mm (0.0142 ~ 0.0386 in) 2.0 mm (0.08 in)
Clutch:	
Friction Plate Thickness/ Quantity <Wear Limit>	3.0 mm (0.12 in) × 7 2.7 mm (0.106 in)



Model	RD350/350F
Clutch Plate	
Thickness/ Quantity <Warpage Limit>	1.2 mm (0.047 in) × 6 0.05 mm (0.002 in)
Clutch Spring	
Free Length/ Quantity	36.4 mm (1.43 in) × 6
Clutch Housing	
Thrust Clearance	0.07 ~ 0.12 mm (0.003 ~ 0.005 in)
Radial Clearance	0.011 ~ 0.048 mm (0.0004 ~ 0.0019 in)
Clutch Release Method	Inner push, Cam push
Push Rod Bending Limit	0.2 mm (0.008 in)
Primary Reduction Gear Back Lash	
Tolerance	154 ~ 156
Primary Drive Gear Back Lash Number	90 ~ 98
Primary Driven Gear Back Lash Number	57 ~ 65
Transmission:	
Main Axle Deflection Limit	0.08 mm (0.0031 in)
Drive Axle Deflection Limit	0.08 mm (0.0031 in)
Shifter:	
Type	Cam drum
Guide Bar Bending Limit	0.025 mm (0.001 in)
Kick Starter:	
Type	Kick and mesh type
Kick Clip Friction Force	P = 0.8 ~ 1.3 kg (1.8 ~ 2.9 lb)
Air Filter — Oil Grade	Foam-Air-Filter Oil or SAE 10W30 SE motor oil
Reed Valve:	
Material	SUS
Bending Limit	0.5 mm (0.02 in)
Valve Stopper Height	10.3 ± 0.2 mm (0.41 ± 0.008 in)
Carburetor:	
Type/ Manufacturer/ Quantity	VM26SS/ MIKUNI/ 2
I.D. Mark	31K00
Main Jet (M.J.)	#240
Air Jet (A.J.)	ø0.7
Jet Needle - Clip Position (J.N.)	5K1-4
Needle Jet (N.J.)	P-0 (345)
Cutaway (C.A.)	2.0
Pilot Jet (P.J.)	#22.5
Air Screw (Turns Out)(A.S.)	1 and 1/4
Starter Jet (G.S.)	#80
Float Height (F.H.)	21 ± 0.5 mm (0.83 ± 0.02 in)
Engine Idling Speed	1,200 ± 50 r/min



Model	RD350/350F
Lubrication:	
Autolube Pump	
Color Code	Yellow
Minimum Stroke	0.10 ~ 0.15 mm (0.004 ~ 0.006 in)
Maximum Stroke	2.05 ~ 2.27 mm (0.08 ~ 0.09 in)
Minimum Output/200 Stroke	0.12 ~ 0.19 cm <sup>3</sup> (0.004 ~ 0.007 Imp oz, 0.004 ~ 0.006 US oz)
Maximum Output	2.58 ~ 2.85 cm <sup>3</sup> (0.091 ~ 0.101 Imp oz, 0.087 ~ 0.096 US oz)
Pulley Adjusting Position (Adjusting Mark)	At idle
	
Cooling:	
Radiator Core Size	
Width	290.6 mm (11.44 in)
Height	180 mm (7.08 in)
Thickness	16 mm (0.63 in)
Radiator Cap Opening Pressure	$89.3 \pm 14.7 \text{ kPa}$ ( $0.9 \pm 0.15 \text{ kg/cm}^2$ , $12.8 \pm 2.13 \text{ psi}$ )
Coolant Capacity (Total)	1.5 L (1.32 Imp qt, 1.59 US qt)
Water Pump	
Type	Single-suction centrifugal pump
Reduction Ratio	32/20 (1.60)
Thermostat:	
Opening Temperature	$71^\circ \pm 2^\circ\text{C}$ ( $156 \pm 35.6^\circ\text{F}$ )
Full Open Temperature/ Lift	$85^\circ\text{C}$ ( $185^\circ\text{F}$ )/7 mm (0.28 in)



## Tightening torque

Part	Thread size	Nm	m · kg	ft · lb	Remarks
Cylinder head	M 8 × 1.25	28	2.8	20	
Cylinder	M 8 × 1.25	25	2.5	18	
Spark plug	M14 × 1.25	20	2.0	14	
Y.P.V.S. Valve	M 5 × 0.8	6	0.6	4.3	
Pulley	M 6 × 1.0	10	1.0	7.2	
Shift pedal	M 6 × 1.0	16	1.6	11	
Reed valve	M 3 × 0.5	1	0.1	0.7	
Joint cover (Thermostatic valve)	M 6 × 1.0	12	1.2	8	
Housing cover	M 6 × 1.0	8	0.8	5.8	
Radiator cover	M 5 × 0.8	3	0.3	2	
Joint (Cylinder head)	M 6 × 1.0	12	1.2	8	
Thermosenser	M10	14	1.4	10	
Oil pump	M 5 × 0.8	5	0.5	3.6	
Reed valve assembly	M 6 × 1.0	15	1.5	11	
Primary drive gear	M16 × 1.0	65	6.5	47	
Clutch boss	M20 × 1.0	90	9.0	65	
Clutch spring	M 6 × 1.0	10	1.0	7.2	
Drive sprocket	M18 × 1.0	80	8.0	58	
Kick crank	M 8 × 1.25	25	2.5	18	
Shift pedal	M 6 × 1.0	16	1.6	11	
Flywheel magneto	M12 × 1.25	85	8.5	61	
Exhaust pipe	M 8 × 1.25	18	1.8	13	
Drain plug (Transmission)	M14 × 1.5	20	2.0	14	
(Coolant)	M 6 × 1.0	14	1.4	10	
Crankcase cover (R)	M 6 × 1.0	10	1.0	7.2	
(L)	M 6 × 1.0	7	0.7	5.1	
Crankcase (Lower)	M 8 × 1.25	15	1.5	10	
(Upper)	M 8 × 1.25	10	1.0	7.2	
Bearing cover plate	M 6 × 1.8	10	1.0	7.2	
Tachometer stopper plate	M 5 × 0.8	5	0.5	3.6	
Shift cam stopper plate	M 6 × 1.0	10	1.0	7	
Stopper lever	M 6 × 1.0	14	1.4	10	
Neutral switch	M 5 × 0.8	4	0.4	2.9	
Shift lever adjust screw	M 8 × 1.25	30	3.0	22	



## Chassis

Model	RD350/350F
Steering System:	
Steering Bearing Type	Ball bearing
No. / Size of Balls	
Upper	19 pcs. 1/4 in
Lower	19 pcs. 1/4 in
Lock to Lock Angle	80°
Front Suspension:	
Front Fork Travel	140 mm (5.51 in)
Front Fork Spring	
Free Length	429.6 mm (16.9 in)
Spring Rate	$K_1 = 3.33 \text{ N/mm}$ (0.34 kg/mm, 19.0 lb/in) 0 ~ 140 mm (0 ~ 5.51 in)
Oil Capacity	297 cm³ (10.48 Imp oz, 10.04 US oz)
Oil Level	106.1 mm (4.18 in)
Oil Grade	Fork oil 10wt or equivalent
Air Pressure (STD)	39 kPa (0.4 kg/cm², 5.7 psi)
(Min. ~ Max.)	0 ~ 118 kPa (0 ~ 1.2 kg/cm², 0 ~ 17 psi)
Rear Suspension:	
Shock Absorber Travel	40 mm (1.57 in)
Rear Wheel Travel	100 mm (3.94 in)
Rear Absorber Spring	
Free Length	186 mm (7.32 in)
Spring Rate	$K_1 = 103.0 \text{ N/mm}$ (10.5 kg/mm, 588 lb/in) 0 ~ 40 mm (0 ~ 1.57 in)
Gas Properties	Nitrogen gas
Gas Pressure	1,177 kPa (12 kg/cm², 171 psi)
Rear Arm:	
Swing Arm Free Play	
End	1 mm (0.04 in)
Side	0.1 ~ 0.3 mm (0.004 ~ 0.012 in)
Wheel:	
Type	Cast wheel
Rim Size/Material (Front)	MT2.15 × 18/ Aluminum
Rim Size/Material (Rear)	MT2.50 × 18/ Aluminum
Rim Run Out Limit	
Vertical	1 mm (0.04 in)
Lateral	0.5 mm (0.02 in)
Drive Chain:	
Type/ Manufacturer	520V-SR/ DAIDO
Number of Links	106
Chain Slack	30 ~ 40 mm (1.18 ~ 1.57 in)



Model		RD350/350F
Disc Brake:		
Type		
Front		Dual
Rear		Single
Disc Size-Outside Dia × Thickness		267 × 5 mm (10.5 × 0.19 in)
Disc Wear Limit		4.5 mm (0.18 in)
Pad Thickness		5.5 mm (0.22 in)
Pad Wear Limit		0.5 mm (0.02 in)
Master Cylinder Inside Diameter	Front	15.87 mm (0.62 in)
	Rear	12.70 mm (0.51 in)
Caliper Cylinder Inside Diameter	Front	38.18 mm (1.5 in)
	Rear	38.18 mm (1.5 in)
Brake Fluid Type		DOT#3

### Tightening torque

Part	Thread size	Nm	m • kg	ft • lb
Engine mounting bolt	M10 × 1.25	64	6.4	46
Engine mount stay	M 8 × 1.25	23	2.3	17
Tension rod	M 8 × 1.25	25	2.5	18
Handle crown -Steering shaft	M14 × 1.25	85	8.5	61
-Inner tube	M 8 × 1.25	20	2.0	14
Handle bar -Inner tube	M 8 × 1.25	20	2.0	14
Handle bar -Handle crown	M 6 × 1.0	9	0.9	6.5
Under bracket -Inner tube	M 8 × 1.25	20	2.0	14
Fork brace	M 6 × 1.0	10	1.0	7.2
Front wheel axle	M12 × 1.25	75	7.5	54
Pivot shaft	M14 × 1.5	90	9.0	65
Rear wheel axle	M14 × 1.5	105	10.5	75
Sprocket wheel	M 8 × 1.25	32	3.2	23
Rear shock -Frame	M10 × 1.25	40	4.0	29
Relay arm -Frame	M10 × 1.25	40	4.0	29
Relay arm -Arm 1, 2	M14 × 1.5	65	6.5	47
Arm 1, 2 -Swing arm	M12 × 1.25	40	4.0	29
Brake disc -Hub	M 8 × 1.25	20	2.0	14
Master cylinder	M10 × 1.25	10	1.0	7.2
Brake hose	M10 × 1.25	26	2.6	19
Retaining bolt	M 6 × 1.0	20	2.0	14
Caliper -Bracket	M10 × 1.25	35	3.5	25
-Bleed screw	M 7 × 1.0	5	0.5	3.6
Frame -Muffler bracket	M10 × 1.25	64	6.4	46
Muffler bracket -Footrest	M10 × 1.25	64	6.4	46



## Electrical

Model	RD350/350F
Ignition System: Ignition Timing: (B.T.D.C.) Advanced Timing: (B.T.D.C.)	17° at 1,200 r/min 27° at 3,500 r/min
<p>Ignition Timing (B.T.D.C.)</p> <p>Engine Speed (<math>\times 10^3</math> r/min)</p>	
CDI: CDI Unit-Model/ Manufacturer Pickup Coil Resistance (Color) Source Coil Resistance (Color)	51L/NIPPONDENSO $117\Omega \pm 20\%$ (White/ Red — White/ Green) $113\Omega \pm 20\%$ (Brown — Green) $4.1\Omega \pm 20\%$ (Brown — Red)
Ignition Coil: Model/ Manufacturer Minimum Spark Gap Primary Winding Resistance Secondary Winding Resistance	12900-027/NIPPONDENSO 6 mm (0.24 in) $0.33\Omega \pm 10\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ ) $3.5\text{k}\Omega \pm 20\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ )
Spark Plug: Type/ Manufacturer	BR8ES/ N.G.K.
C.D.I. Unit: Type/ Manufacturer	52Y/NIPPONDENSO
A.C. Generator: Model/ Manufacturer Charging Output	51L/NIPPONDENSO 14V14A/5,000 r/min
<p>Output Current (A)</p> <p>Engine Speed (<math>\times 10^3</math> r/min)</p>	
Charging Coil Resistance (Color)	$0.5\Omega \pm 20\%$ at $20^\circ\text{C}$ ( $68^\circ\text{F}$ ) (White — White)




Model	RD350/350F
Voltage Regulator:	
Type	Short circuit
Model/ Manufacturer	SH235-12C/ SHINDENGEN KOUYOU
Regulating Voltage	14.5 ± 0.5V
Rectifier:	
Type	Three phase, Full wave
Model/ Manufacturer	SH235-12C/ SHINDENGEN KOUYOU
Capacity	15A
Withstand Voltage	200V
Battery:	
Model/ Manufacturer	12N5.5-3B/ NIPPONDENSO
Charging Rate	0.55A × 10 hours
Specific Gravity	1,280
Horn:	
Model	CF-12/ NIKKO
Maximum Amperage	2.5A or less
Flasher Relay:	
Type	Semi transistor type
Model/ Manufacturer	FJ245ED/ NIPPONDENSO
Flasher Frequency	85 cycle/min
Capacity	12V, 21W × 2 + 3.4W
Thermo-unit:	
Model/ Manufacturer	YA55901NO/NISSEI
Circuit Breaker:	
Type	Fuse
Amperage for Individual Circuit/ Quantity	
Main	20A × 1
Headlight	15A × 1
Signal	15A × 1
Y.P.V.S.	5A × 1
Reserve	20A × 1, 15A × 1, 5A × 1



## **GENERAL TORQUE SPECIFICATIONS**

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.

A (Nut)	B (Bolt)	General torque specifications		
		Nm	m·kg	ft·lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94



A: Distance cross flats

B: Outside thread diameter

## **DEFINITION OF UNITS**



Unit	Read	Definition	Measure
mm	millimeter	$10^{-3}$ meter	Length
cm	centimeter	$10^{-2}$ meter	Length
kg	kilogram	$10^3$ gram	Weight
N	Newton	$1 \text{ kg} \times \text{m/sec}^2$	Force
Nm	Newton meter	$\text{N} \times \text{m}$	Torque
$\text{m} \cdot \text{kg}$	Meter kilogram	$\text{m} \times \text{kg}$	Torque
Pa	Pascal	$\text{N/m}^2$	Pressure
N/mm	Newton per millimeter	$\text{N/mm}$	Spring rate
L	Liter	—	Volume
$\text{cm}^3$	Cubic centimeter	—	or Capacity
r/min	Rotation per minute	—	Engine Speed



## CABLE ROUTING

- ① Cable holder
- ② Throttle cable 1, 2
- ③ Handlebar switch lead (Right)
- ④ Handlebar switch lead (Left)
- ⑤ Clutch cable
- ⑥ Main switch lead
- ⑦ Handlebar switch lead (Right)
- ⑧ Clutch cable
- ⑨ Meter lead
- ⑩ Horn lead

- ⑪ Front flasher light lead (Left)
- ⑫ Speedometer cable
- ⑬ Wire harness
- ⑭ Brake hose 2
- ⑮ Front flasher light lead (Right)
- ⑯ Brake hose 1
- ⑰ Throttle cable 1, 2
- ⑱ Handlebar switch lead (Right)
- ⑲ Meter ass'y





## CABLE ROUTING


- ① Rectifier/regulator
- ② C.D.I. unit
- ③ Thermo-unit lead
- ④ Servomotor
- ⑤ Throttle cable 2
- ⑥ Clutch cable
- ⑦ Brake hose 1
- ⑧ Handlebar switch lead (Right)
- ⑨ Clamp
- ⑩ Horn lead (Left)
- ⑪ Speedometer cable
- ⑫ Brake hose 2
- ⑬ Throttle cable 1
- ⑭ Y.P.V.S. cable
- ⑮ Clamp

- ⑯ Pump cable
- ⑰ Battery breather hose
- ⑱ Brake switch Ass'y
- ⑲ Oil tank breather hose
- ⑳ Battery negative terminal
- ㉑ Wire harness
- ㉒ Battery negative lead
- ㉓ Battery positive lead
- ㉔ Battery positive terminal
- ㉕ Earth terminal
- ㉖ C.D.I. magneto lead
- ㉗ C.D.I. unit lead
- ㉘ Band
- ㉙ Oil hose

**A** HOLD THE CLUTCH CABLE WITH THE CLAMP.

**B** ROUTE THE CDI MAGNETO LEADS BEHIND THE ENGINE BRACKET, AND CONNECT THEM.

**C** ROUTE THE STOP SWITCH LEADS BEHIND THE ENGINE BRACKET.






## CABLE ROUTING

- |                                 |                                |
|---------------------------------|--------------------------------|
| ① Handlebar switch lead (Right) | ⑯ Y.P.V.S. control unit lead   |
| ② Main switch lead              | ⑰ Flasher lead (Right)         |
| ③ Servomotor                    | ⑱ Flasher lead (Left)          |
| ④ Thermo unit lead              | ⑲ Wire harness                 |
| ⑤ Servomotor lead               | ⑳ Tail/Brake light lead        |
| ⑥ Rectifier/regulator lead      | ㉑ Clamp                        |
| ⑦ Frame earth lead              | ㉒ Y.P.V.S. control unit        |
| ⑧ C.D.I. unit lead              | ㉓ Fuse box                     |
| ⑨ Flasher relay lead            | ㉔ Oil tank breather hose       |
| ⑩ Brake switch lead             | ㉕ Flasher relay                |
| ⑪ Earth terminal                | ㉖ C.D.I. unit                  |
| ⑫ C.D.I. magneto lead           | ㉗ Rectifier/regulator lead     |
| ⑬ Battery positive lead         | ㉘ Plug cord                    |
| ⑭ Battery negative lead         | ㉙ Ignition coil                |
| ⑮ Oil level gauge lead          | ㉚ Ignition coil lead           |
| ⑯ Y.P.V.S. control unit lead    | ㉛ Handlebar switch lead (Left) |

**A** SECURE THE LEADS WITH THE CLAMP.

**B** CONNECT THE GROUND LEAD TO THE SCREW ON THE REAR OF THE IGNITION COIL AND TIGHTEN THE SCREW.



O